

AeroCab Install

1. You will need to remove the electric wing mechanism from the decklid before bolting the new Aerocab wing into the decklid recess.
2. Remove the tray covering the electric motor.



3. Raise the electric wing. Loosen the pinch bolts securing the back edge of the plastic grill then tilt and remove.





4. Remove the press on clips that hold the support rail securing the bottom of the bellows.



5. Remove the four bolts holding the plastic tray to the top of the piston.



6. Remove the 4 bolts from the hinge holding the plastic tray to the front of the decklid.



7. Remove the allen head bolts securing the piston assemblies to the decklid.



8. Remove the piston assemblies motor and wiring harness as one unit.
9. Check fit of AeroCab grill into liner. Use clay to locate any high spots that will need to be relieved. Follow FRP Tech on post-curing before any paint prep.

